



Pressure Vs Torque Conversion Chart				
<i>Titan T8 Square Drive Tool</i>				
Pressure	<i>Torque</i>		Pressure	<i>Torque</i>
Psi	<i>Ft-Lb</i>		Bar	<i>Kgm Nm</i>
1500	1168		103	161 1584
1600	1246		110	172 1689
1800	1402		124	193 1901
2000	1574		138	217 2134
2200	1731		152	239 2348
2400	1889		166	261 2561
2600	2046		179	282 2775
2800	2204		193	304 2988
3000	2378		207	328 3225
3200	2537		221	350 3440
3400	2695		235	372 3655
3600	2854		248	394 3869
3800	3012		262	416 4084
4000	3216		276	444 4361
4200	3377		290	466 4579
4400	3538		304	488 4797
4600	3698		317	510 5015
4800	3859		331	533 5233
5000	3990		345	551 5410
5200	4150		359	573 5627
5400	4309		373	595 5843
5600	4469		386	617 6060
5800	4628		400	639 6276
6000	4848		414	669 6574
6200	5010		428	691 6793
6400	5171		442	714 7012
6600	5333		455	736 7231
6800	5494		469	758 7450
7000	5660		483	781 7675
7200	5822		497	803 7894
7400	5983		511	826 8114
7600	6145		524	848 8333
7800	6307		538	870 8552
8000	6476		552	894 8781
8200	6638		566	916 9001
8400	6800		580	938 9221
8600	6962		593	961 9440
8800	7124		607	983 9660
9000	7240		621	999 9817
9200	7401		635	1021 10036
9400	7562		649	1044 10254
9600	7723		662	1066 10472
9800	7884		676	1088 10690
10000	8062		690	1113 10932